

**ENGINE CONTROL PANEL**

**CM 20/30  
SERIES**

*USER'S MANUAL*

 **PINE** *s.r.l.*  
SISTEMI ELETTRONICI

## INDEX

<b>1. INTRODUCTION .....</b>	<b>3</b>
<b>2. INSTALLATION .....</b>	<b>3</b>
<b>3. GENERAL FEATURES .....</b>	<b>3</b>
<b>4. ALARMS, SIGNALING AND COMMANDS.....</b>	<b>4</b>
<b>5. PANEL SWITCHING ON AND ENGINE STARTING .....</b>	<b>4</b>
<b>6. ENGINE STOP BY CURRENT REMOVING .....</b>	<b>4</b>
<b>7. ENGINE STOP BY CURRENT SENDING .....</b>	<b>4</b>
<b>8. AUTOMATIC STOP .....</b>	<b>5</b>
<b>9. PREHEATING .....</b>	<b>5</b>
<b>10. RPM CALIBRATION .....</b>	<b>5</b>
<b>11. ADJUSTEMENT OF ENGINE WORKING HOURS .....</b>	<b>6</b>
<b>12. LEVEL TRANSDUCER CALIBRATION.....</b>	<b>6</b>
<b>13. ANOMALIES IN THE ENGINE ELECTRICAL ASSEMBLY .....</b>	<b>6</b>
<b>14. SWITCHED-ON PANEL SIGNALING .....</b>	<b>7</b>
<b>15. CONTROL BY TWO PANELS.....</b>	<b>7</b>
<b>16. CODE DESCRIPTION.....</b>	<b>7</b>
<b>17. TECHNICAL SPECIFICATIONS.....</b>	<b>8</b>
<b>18. CONFORMALITY DECLARATION .....</b>	<b>8</b>




Fig. 1 - CM20/30 panel

## 1. INTRODUCTION

CM20/30 is an engine control panel based on microprocessor.  
It reads common commercial signals. On request it can be adapted to any kind of transducer.

## 2. INSTALLATION

CM20 and CM30 series engine control panels must be placed on the pilot bridge of ship or alternatively, on a board protecting the back from water. D6 drawing indicates cutting for a correct assembly.

It is recommended to add a seal on the cutting edge to protect the panel from water.  
Lock it with the supplied screws.

The connection to the engine is obtained by coupling panel connector with engine connector. Electrical schemes are on D3 drawing and connector numbering is on D1 drawings.  
If panel is not supplied with electric wiring, see D1, D2 and D3 drawings.

### ALARMS AND AUTOMATIC STOP TEST

It is possible to test correct working of alarms (that are not normally active in a regularly running engine) by connecting the alarm contacts to negative pole of Battery on the engine side.

If panel is set for automatic stop it is possible to test this function simulating an alarm when the engine is running; the switch (16) must be on the STOP AUT position.

**It is advisable to test all the alarms.**

## 3. GENERAL FEATURES

- 6 measurements led displayed in three rows
  - 1st ROW: RPM / Working hours
  - 2nd ROW: Water Temperature / Level
  - 3rd ROW: Oil Pressure (or Oil Temperature) / Battery Voltage
- 7 warning lamps for signalings and alarms
- Acoustic alarm and key to silence it
- Variable luminous intensity
- Automatic stop function with possibility of excluding it by switch (16) in STOP MAN
- Power supply: 12 Vcc for CM20 series – 12 / 24 Vcc for CM30 series
- Dimensions: 243.0 x 135.5 mm

On request:

- Connection of two panel in parallel (“Master-Slave” configuration)
- Set of pre-alarm and alarm thresholds in any measurement
- Maintenance or oil-change management (by settable timer)
- Overspeed alarm
- Remote silencing key (CM30 series only)

#### 4. ALARMS, SIGNALING AND COMMANDS (ref. to fig. 1)

1 - LOW OIL PRESSURE warning lamp	ON/OFF ALARM
2 - HIGH WATER TEMPERATURE warning lamp	ON/OFF ALARM
3 - ALTERNATOR (BATT. CHAR.) warning lamp	SIGNALING
4 - LOW BATTERY VOLTAGE warning lamp	SIGNALING
5 - ALARM 2 warning lamp (CM30 only)	ON/OFF ALARM
6 - ALARM 1 warning lamp	ON/OFF ALARM
7 - PREHEATING warning lamp	SIGNALING
8 - SILENCE KEY	
9 - DECREASES DISPLAY LUMINOSITY	
10 - INCREASES DISPLAY LUMINOSITY	
11 - Selects alternatively visualization of ENGINE RPM / WORKING HOURS	
12 - Selects alternatively visualization of WATER TEMPERATURE / LEVEL	
13 - Selects alternatively visualization of OIL PRESSURE / BATTERY VOLTAGE	
14 - KEY FOR SWITCHING ON PANEL AND STARTING ENGINE	
15 - FUSE	
16 - ACTIVATES / DISACTIVATES ENGINE AUTOMATIC STOP	
17 - BUZZER	
18 - PUSH-BUTTON FOR ENGINE STOP (panel must be on to perform stop operation)	

Each **ON/OFF ALARM** activates buzzer (acoustic alarm) and warning lamp.  
**SIGNALING** is a luminous warning only.

#### 5. PANEL SWITCHING ON AND ENGINE STARTING

- One-second “Lamp-Test” is executed
- **Low Oil Pressure** warning lamp (1) and **Alternator** warning lamp (3) are on
- Buzzer, meaning low oil pressure, is on
- If needed, wait for preheating time before engine ignition
- Engine starting involves buzzer turning off (it can be reactivated when a new alarm is on)

#### 6. ENGINE STOP BY CURRENT REMOVING

If panel hasn't a stop-push, engine can be stopped by turning off the panel by its key.  
 Otherwise, press STOP-push (18) until the engine stops. Panel **must be on**.

#### 7. ENGINE STOP BY CURRENT SENDING

This operation is performed by pressing STOP button (18) until the engine stops.  
 Panel **must be on**.

## 8. AUTOMATIC STOP

If panel has this option, it can stop the engine in the following cases:

- Low oil pressure alarm activated - warning lamp (1) on
- High water temperature alarm activated - warning lamp (2) on
- Overspeed alarm activated - RPM value blinking

**Panel can perform the engine automatic stop if switch (16) is on STOP AUT position.**

On STOP MAN position, engine can be manually stopped only.

STOP MAN position is recommended when stopping the engine can make a greater damage than leaving it running.

## 9. PREHEATING

This function is active only if **RL1** is connected to **P12** as shown in D5 drawings.

Preheating warning lamp (7) is turned on for a time depending on engine water temperature.

In absence of water temperature transducer or if this is disconnected, preheating time is always 20 seconds (see Cap. 17, "Technical specifications").

Post-heating: after preheating lamp is off, heating plugs are power supplied for further 5 secs.

Engine ignition: heating plugs are power supplied for the whole operation plus 5 secs.

## 10. RPM CALIBRATION

The measurement of RPM must be adjusted during installation to adapt it to the number of pulses coming from alternator "W" contact or from other magnetic transducers.

- 1 Start up the engine and hold it at a stable number of RPM (for example at 1,000 RPM)
- 2 Measure true RPM value by a **precision revolution counter**
- 3 Press key (11) for 6-7 seconds; buzzer will produce a "beep"
- 4 **Without releasing key (11)**, adjust the measure pressing keys (9) and (10) to respectively decrease or increase the visualized RPM
- 5 Once the right measure is reached, release key (11) to store in memory this calibration

If necessary, these operation can be performed again.

Alternatively, knowing the impulse number per engine revolution (or the number of teeth of the crown wheel), please repeat the operations shown before changing point 4 as following:

- 4a **Without releasing key (11)**, press key (8) and adjust the measure by key (9) and (10) to respectively increase or decrease the impulse number per engine revolution.

**Note:** if panel is supplied with a Pine pick-up adaptor, the impulse number is given dividing the number of teeth of the crown wheel by 16.

## 11. ADJUSTEMENT OF ENGINE WORKING HOURS

This operation must be done when **engine is not running**.

- Switch on the panel keeping key (8) pressed
- **Without releasing the key**, change the engine working hours using keys (9) and (10)
- Releasing key (8), the new value will be stored in memory

## 12. LEVEL TRANSDUCER CALIBRATION

**Note:** display must visualize the measure to calibrate.

### Low level calibration (0%)

- Move the transducer to the min level position and wait for a stable reading
- Keep key (9) and key (13) pressed
- After 20 seconds, buzzer will produce a “beep”: 0% level is stored

### Max level calibration (100%)

- Move the transducer to the max level position and wait for a stable reading
- Keep key (10) and (13) pressed
- After 20 seconds, buzzer will produce a “beep”: 100% level is stored

Warning: if display visualizes “**Err**”, move the transducer to a mid position storing it as max. Then restart from low level calibration. “**Err**” also indicates a transducer damage.

## 13. ANOMALIES IN THE ENGINE ELECTRICAL ASSEMBLY

### **IMPORTANT: Low Oil Pressure (1) alarm**

When engine is not running, warning lamp (1) and acoustic alarm are activated.  
If not, PRESSURE SWITCH IS DAMAGED OR ITS WIRE IS DISCONNECTED.

### RPM measurement

- Connecting wire to alternator or to transducer is interrupted: RPM remains at 0000 value.

### Water (Oil) temperature measurement

- Connecting wire or transducer is interrupted: visualization disappears from display
- In case of short circuit to the negative pole of Battery, the **EEE** message appears.

### Oil pressure measurement

- Connecting wire or transducer is interrupted: visualization disappears from display
- In case of short circuit to the negative pole of Battery, **EEE** is displayed for Veglia transducer, **00.0** for VDO transducer.

### Level measurement

- Connecting wire or transducer is interrupted: visualization disappears from display
- In case of damage or bad calibration: **Err** is displayed.

**14. SWITCHED-ON PANEL SIGNALING**

An acoustic alarm is present to avoid leaving the panel on. If the engine is not running and the panel is switched on, buzzer produces an intermittent sound after 20 seconds. It can be interrupted by an engine starting only.

**15. CONTROL BY TWO PANELS**

In order to perform the engine control by two panels, the followings are necessary:

- a normal panel named “**Host**”
- a panel arranged for this application named “**Slave**”

Switching-on one of the two panels involves switching-on of the other, therefore **panel switching-on, engine ignition and engine stop must be activated from one panel only.**


Engine stop by current removing:

- **Manual stop** is executed by turning off rotating key on the same panel used for starting. If erroneously both panels are switched-on, stopping engine from one panel only will not be possible. Engine will be stopped when both rotating keys will be turned to off position.
- (if prevent) **Automatic stop** is always active even if both panels are switched-on from “Slave”. STOP MAN/STOP AUT switch is present on “Host” only. In case of erroneous switching-on of both panels, see manual stop instruction.

Engine stop by current sending:

- **Manual stop** can be performed from both panels.
- (if prevent) Automatic stop is active even if panels are switched-on from “Slave”. STOP MAN/STOP AUT switch is present on “Host” only.

**16. CODE DESCRIPTION**



**17. TECHNICAL SPECIFICATIONS**


POWER SUPPLY	CM20 12 Vcc (min 6V, max 15V)	CM30 12/24Vcc (min 10, max 30V)
POWER CONSUMPTION	Less than 6 Watt	
PROTECTIONS	Polarity inversion, Battery disconnecting extravoltage (not repeatitive)	
WORKING TEMPERATURE	- 10 °C / + 60 °C	
STORAGE TEMPERATURE	- 30 °C / + 70 °C	
VISUALIZATION	3 rows display and variable luminous intensity	
WARNING LAMP	Low Oil Pressure (BPO) High Water Temperature (ATA) Alternator (D+) Low Battery Alarm 1 (AL1) Alarm 2 (AL2 – CM30 only) Preheating	
ACOUSTIC INDICATION	Buzzer 5 – 30 Vcc	
PREHEATING TIME (ref. to engine water temperature)	0 °C 15 seconds 20 °C 10 seconds 40 °C 7 seconds >50 °C 0 seconds -- 20 seconds (without control or negative temp.)	
TRANSDUCER TYPE	ENGINE REVOLUTION	Alternator “W” contact
		Pick-up on crown wheel (by Pine adaptor)
		Proximity swich (on request)
	WATER (OIL) TEMPERATURE	VDO 40 – 120 °C
		Veglia 40 – 120 °C
		Jaeger 40 – 120 °C (on request)
		0 – 20 mA or 4 – 20 mA (on request)
	OIL PRESSURE	VDO 0 – 10 bar
		VDO 0 – 25 bar (on request)
		Veglia 0 – 10 bar
		Jaeger 0 – 10 bar (on request)
		Jaeger 0 – 25 bar (on request)
0 – 20 mA or 4 – 20 mA (on request)		
LEVEL	Resistor type	
Note: for other type of transducer, please call PINE s.r.l.		

**18. CONFORMALITY DECLARATION**

Manufactures declares that the engine control panel of series CM02/CM30 is in conformity at European requisition of electromagnetic compatibility and of security with directives 73/23/EEC, 89/336/EEC, 92/31/EEC, 93/68/EEC and 93/97/EEC and EN60945 directives.

**SERIE CM20/30 :  
CM20/30 SERIES :**

**VISTA POSTERIORE  
BACK VIEW**



**LEGENDA / LEGEND**

- BPO ALLARME BASSA PRESSIONE OLIO  
LOW OIL PRESSURE ALARM
- ATA ALLARME ALTA TEMPERATURA ACQUA  
HIGH WATER TEMPERATURE ALARM
- P.O. LETTURA PRESSIONE OLIO  
OIL PRESSURE SIGNAL
- AVV AVVIAMENTO  
STARTING
- SIR COMANDO ALLARME SONORO (POLO NEGATIVO DEL BUZZER)  
ACOUSTIC ALARM (NEGATIVE POLE OF BUZZER)
- T.A. LETTURA TEMPERATURA ACQUA  
WATER TEMPERATURE SIGNAL
- D+ (SPIA ALTERNATORE)  
BATTERY CHARGING SIGNAL
- P12 COLLEGAMENTO RELE' PRE-RISCALDO  
PREHEATING RELAY CONNECTION
- +B POSITIVO BATTERIA  
POSITIVE POLE OF POWER SUPPLY
- RPM LETTURA GIRI MOTORE  
REVOLUTION SIGNAL
- GND NEGATIVO BATTERIA  
NEGATIVE POLE OF POWER SUPPLY
- C COMUNE CONTATTI RELE' (SOLO CON ARRESTO AUTOMATICO)  
RELAY COMMON CONTACT (ONLY FOR AUTOMATIC STOP)
- NC CONTATTO RELE' NORMALMENTE CHIUSO (SOLO CON ARRESTO AUT.)  
NORMALLY CLOSE CONTACT (ONLY FOR AUTOMATIC STOP)
- NO CONTATTO RELE' NORMALMENTE APERTO (SOLO CON ARRESTO AUT.)  
NORMALLY OPEN CONTACT (ONLY FOR AUTOMATIC STOP)
- LIV LETTURA LIVELLO  
LEVEL SIGNAL
- AL1 ALLARME 1 (ATTIVO AL NEGATIVO BATTERIA)  
ALARM 1 (ACTIVE TO NEGATIVE POLE OF BATTERY)
- AL2 ALLARME 2 - SOLO CM30 (ATTIVO AL NEGATIVO BATTERIA)  
ALARM 2 - CM30 ONLY (ACTIVE TO NEGATIVE POLE OF BATTERY)

RIF. FILE / FILE REF. : DSDXC3001A

DATA / DATE : 01/03/2001

SCALA / SCALE : D1

DESCRIZIONE / DESCRIPTION : CONNETTORI CENTRALINA ELETTRONICA DI CONTROLLO

REV. / REV. : A

FOLLIO / SHEET : D1


DESIGNATO / DESIGNED : DA RE L.

APPROVATO / APPROVED : BOSCARATO A.



**CONNETTORI CENTRALINA  
ELETTRONICA DI CONTROLLO  
ELECTRONIC CONTROL UNIT CONNECTORS**


# SERIE /SERIES CM20/30




RIF. FILE / FILE REF. :	DATA / DATE :	SCALA / SCALE :	DESCRIZIONE / DESCRIPTION :
DSEXC3027A	23/01/2001		CABLAGGIO PANNELLO CON ARRESTO AUTOMATICO A LANCIO DI CORRENTE / PANEL ASSEMBLY WITH AUTOMATIC STOP BY CURRENT SENDING
CODICE / CODE :	REV. / REV. :	FOGLIO / SHEET :	
DSEXC3027A	A	D3	
DISEGNATO / DESIGNED :		DA REL. :	
		BOSCARATO A.	
		APPROVATO / APPROVED :	



# SERIE / SERIES CM20/30



# SERIE/SERIES CM20/CM30



RIF. FILE / FILE REF.: DATA / DATE:

DSDXC3004A 01/03/2001

SCALA / SCALE:

D4

DESCRIZIONE / DESCRIPTION:

COLLEGAMENTO PER DOPPIO COMANDO  
CONTROL FROM TWO PANELS

DISGNATO / DESIGNED:


DA REL.

APPROVATO / APPROVED:  
BOSCARATO A.

**PINE** S.r.l.  
Chiggia (VE) - Italy


# SERIE/SERIES CM2A/CM3A

QUADRO SENZA PRE-RISCALDO  
 PANEL WITHOUT PREHEATING




P12 non collegato  
 P12 unconnected

24V CON PRE-RISCALDO  
 24V WITH PREHEATING




Il rele' RL1 (24V, 50A)  
 viene comandato da P12  
 RL1 relay (24V, 50A) is  
 connected to P12

12V CON PRE-RISCALDO  
 12V WITH PREHEATING



Il rele' RL1 (12V, 70A)  
 viene comandato da P12  
 RL1 relay (12V, 70A) is  
 connected to P12


24V CON PRE-RISCALDO  
 24V WITH PREHEATING



Il rele' RL1 (12V, 70A)  
 viene comandato da P12  
 tramite un resistore  
 RL1 relay (12V, 70A) is  
 connected to P12  
 by a resistor

RIF. FILE / FILE REF. :	DATA / DATE :	SCALA / SCALE :	DESCRIZIONE / DESCRIPTION :
DSDXC3A05A	01/03/2001		GESTIONE PRE-RISCALDO PRE-HEATING MANAGEMENT
CODICE / CODE :	REV. / REV. :	FOLLIO / SHEET :	
DSDXC3A05A	A	D5	
DISEGNATO / DESIGNED : DA RE L.		APPROVATO / APPROVED : PADOAN M.	
 <b>PINE S.r.l.</b> Chioggia (VE) - Italy			

SERIE / SERIES CM20/30



RIF. FILE / FILE REF. :		DATA / DATE :		SCALA / SCALE :		DESCRIZIONE / DESCRIPTION :		DISEGNATO / DESIGNED :	
DSDXC3006A		01/03/2001				DIME DI FORATURA CUTTING EDGE		DA RE L.	
CODICE / CODE :		REV. / REV. :		FOGLIO / SHEET :				APPROVATO / APPROVED :	
DSDXC3006A		A		D6				BOSCARATO A.	
<p><b>PINE</b> S.r.l. Chioggia (VE) - Italy</p>									



